

6141	When calling the <b>KeyChk</b> function, this Error means that the Exec-Count update value is a Positive number. This is not allowed. It must be Zero or a Negative number.
6142	The Execution-Count Limit of the Key has been reached.
6143	The Expire-Date Limit of the Key has been reached.
6144	<p>If you have placed an Expire-Date Limit on the Key, a time stamp is recorded whenever the device is used. This Error means that the current System Date/Time is set prior to that recorded time stamp.</p> <p>This Error may occur if the Key is used on two Systems set to different Time Zones.</p>
6146	When calling the <b>KeyChk</b> function, this Error means that the Exec-Count update value is larger than current Execution-Count Limit of the Key.
6240	When calling the <b>KeyChk</b> function, this Error means that the Secure Communication Block ( <b>SCB</b> ) could not be located.
6241	When calling the <b>KeyChk</b> function, this Error means that the Secure Communication Block ( <b>SCB</b> ) contains an invalid Function-Code field.

# “Preferences” - EverKey System Settings

## ***Errcode Overview***

The **Errcode.exe** program will display information about an **EVERKEY** Error Code that you or your Customers may encounter. When possible, **Errcode.exe** will also suggest a solution to address the problem.

## ***Errcode Operation***

Start the Errcode.exe program from the Windows Start menu shortcut and enter "6043" as the Error Code. Your display should look something like this: